

Filling larger

HOLES, CRACKS OR SPLITS
or building up corners and edges

BRUMMER TWO-PART WOOD FILLER
(FOR INTERIORS AND EXTERIORS)



- 1 Ensure surfaces are clean, dry and structurally sound. To fill large areas insert a non-rusting screw or similar fixing into the wood, leaving the head slightly proud (in the hole but not proud of the surface) to provide an anchor for the filler.
- 2 For best results mix the filler in the following proportions: a 1" (38mm) strip of catalyst to a golf ball sized volume (50gm) of filler. Mix only sufficient for immediate requirements, on a clean, flat surface such as a pane of glass, ensuring that the mixture is thoroughly blended. The working time is approximately 10 minutes at room temperature, slightly longer in cooler temperatures or with less catalyst.
- 3 Apply the mixed paste immediately. A thin coating should be applied first and allowed to dry, followed by enough paste to fill the repair. Leave slightly proud to allow for sanding or planing.
- 4 After approximately thirty minutes the filled area will be hard enough to be planed, filled or sanded to the correct shape. The repair can now be primed, painted or coated to the desired finish. It is also possible to mix two colours of Two-Part Wood Filler together to achieve a different shade but always mix the pastes first to determine the colour before adding the appropriate quantity of hardener. To achieve the best result always try a sample area first. NB: After it has set Two-Part Wood Filler cannot be easily stained or coloured.
- 5 It is also possible to build up edges or corners but this is best achieved in layers, allowing each layer to set before applying the next. This method will reduce the amount of finishing necessary.

BRUMMER

www.woodfillers.co.uk

Filling larger holes, cracks or splits