

# Using Rub In GRAIN FILLER



- 1 *Ensure the area to be filled is clean, dry and free from any particles of dust or grease which may prevent the Grain Filler adhering to the surface.*
- 2 *Mix 2 parts of Grain Filler powder with 1 part water to a creamy consistency.*
- 3 *Dip a soft cloth into the paste and apply to the surface, working into the grain in a circular motion and finishing across the grain. Wipe off any surplus and avoid allowing dried Grain Filler to build up on your cloth as this may scratch fine surfaces.*
- 4 *Allow to dry and sand lightly if necessary. Remove any dust or loose particles and finish or seal as required.*
- 5 *For small areas the Grain Filler may be used straight from the tub and applied with a damp cloth. Dip the cloth into the powder and apply to the surface working into the grain in a circular motion, finishing across the grain. Grain Filler may be used on bare wood to colour it and give a smoother finish before finishing with a clear varnish or polish.*
- 6 *To achieve a limed effect, use white or standard shades, and to achieve an exotic timber appearance with highlighted dark grain use a dark oak or dark mahogany shade and follow the instructions above.  
Remove most of the excess while still damp, with a clean, dry cloth and, depending on the degree of limed effect required this may be all that is necessary prior to applying a finishing or sealing coat. Alternatively, allow to dry, then lightly sand to give a more subtle finish, then wipe away any dust or loose particles and finish or seal as required.*

PREPARES THE GRAIN OF  
ALL WOODEN SURFACES BEFORE  
FINAL DECORATION; ACTS AS A  
PRIMER, FILLER AND SEALER



[www.woodfillers.co.uk](http://www.woodfillers.co.uk)

**BRUMMER**

Using Rub In Grain Filler